

1. Mounting plate type C-MOUNT-LT-37-68/150

The mounting plate **C-MOUNT-LT-37-68/150** is used in connection with the laser sensors type **L-LAS-LT-37-MA** and **L-LAS-LT-37-SL** especially for thickness measurements of objects. Furthermore, the plate can be used just for adjustment of the master and slave sensor. After the adjustment of both sensors, the unit can be removed.

